





INTER

ML-2010 Series ML-2015/XEV

Basic Model: ML-2010

SERVICE Manual

LASER PRINTER



The keynote of Product

 Speed: 22ppm (Ltr) / 20ppm (A4), 600dpi × 1200dpi

- Paper Path : MPF Type Cassette

- Emulation : SPL (ML-2010 / ML-2015)

- Processor : 150MHz Jupiter4e CPU

- Memory: 8MB

- Toner Cartridge : Initial (1K), Sales (3K)

- MP Cassette: 150 pages / Face Down (50 pages)

- Manual Duplex : Manual Feed Guide

- Fuser Design : Lamp Type

- I/O: USB1.1

- Machine Life: 50K(pages)

service repairmanual com



- * This service manual is a property of Samsung Electronics Co., Ltd. Any unauthorized use of Manual can be punished under applicable international and/or domestic law.
- * This service manual is also provided on the web, the ITSELF system Samsung Electronics Co., Ltd.

http://itself.sec.samsung.co.kr

© Samsung Electronics Co.,Ltd. Aug. 2005 Printed in Korea.

VERSION NO.: 1.00 **CODE**: JC-0141I

Contents

1.	Precautions	
	1.1 Cofoty Warning	1-1
	1.1 Safety Warning	
	1.2 Safety Caution 1.3 ESD Precautions	1-2 1-4
	1.3 ESD Precautions	1-4
2.	Product Specification	
	·	
	2.1 Product Overview	2-1
	2.2 Specifications	2-1
	2.3 Model Comparison Table	2-5
•		
3.	System Overview	
	3.1 System Outline	3-1
	3.1 System Outline3.2 H/W Structure and Descriptions	3-7
	3.3 S/W Structure and Descriptions	3-19
	3.4 Initial Product Installation	3-19
	3.4 Illitial Floudet Installation	J-2 4
4.	Alignment and Adjustments	
	50	
	4.1 Sample Pattern	4-1
	4.2 Control Panel	4-2
	4.3 Consumables and Replacement Parts	4-4
	4.4 LED Status Error Messages	4-4
	4.5 Periodic Defective Image	4-5
	4.6 How to use DCU	4-6
	4.7 Paper Path	4-11

Continued

J .	Disassembly and Reassembly	
	5.1 General Precautions on Disassembly	5-1
	5.2 Disassembly and Reassembly	5-2
6.	Troubleshooting	
	6.1 Checking Symptoms	6-1
	6.2 Bad discharge	6-4
	6.3 Malfunction	6-8
	6.4 Bad software environment	6-13
	6.5 Bad Image	6-17
7.	Exploded Views & Parts List	
	7.1 Exploded Views and Parts List	· 7-1
8.	Block diagram	
	8.1 System Block Diagram	8-1
	8.2 System Timing Chart	8-2
9.	Connection Diagram	
	inne	
	9.1 Connection Diagram	9-1
10.	Schematic Diagram	
		40.4
	10.1 Main Board	10-1
	10.2 Connector Circuit Diagram	10-5
	10.3 SMPS Circuit Diagram	10-6
	10.4 HVPS Circuit Diagram	10-7

Continued

11.	Reference Information	lu.
	11.1 Troubleshooting Tools11.2 Acronyms and Abbreviations11.3 Selecting printer locations11.4 Sample Tests Patterns	11-1 11-2 11-4 11-5
12.	Circuit Description	
	12.1 Engine Controller	12-1